


## NRT-Z5 - Installation (Windows 10)

**Step 1:** Start your computer and log in

**Step 2:** Connect the NRT-Z5 to your computer.


Windows 10 will immediately start to look for preinstalled drivers but find none.  
The installation has to be carried out manually as follows ...

**Step 3:** Open the device manager: START → Control Panel → System → Device Manager.  
You will find the NRT-Z5 in the "Other devices" branch of the hardware-tree.




Right-click on the device and select "Update driver" from the context menu.


**Step 4:** From the dialog, select "Browse my computer for drivers"




**Step 5:** Select the drive / folder with the NRT-Z5 setup files.




**Step 6:** Confirm that you want to install the drivers



It may take a few moments until Windows reports success:



**Step 7:** This is a two-stage installation.  
The first part of the driver stack - the port driver - is installed now.  
Now you need to install the driver for the USB serial port:



**Repeat steps 3...6** for the "USB serial port" device.

**Step 8:** Now, the NRT-Z5 is ready for use:

