

R&S® PULSE SEQUENCER SOFTWARE OPTIONS FOR ROHDE & SCHWARZ SIGNAL GENERATORS

Specifications

R&S®SMW200A

R&S®SMBV100A

R&S®SMBV100B

R&S®SGT100A

R&S®SMU200A

R&S®SMJ100A

Data Sheet
Version 09.00

ROHDE & SCHWARZ

Make ideas real



CONTENTS

Definitions	4
Notations and abbreviations.....	5
Introduction	5
I/Q baseband generators and memory size	6
Related documents	7
Key features	8
<i>K300 pulse sequencing option</i>	<i>8</i>
<i>K301 enhanced pulse sequencing option</i>	<i>8</i>
<i>K302 radar platforms option</i>	<i>8</i>
<i>K304 moving emitters option</i>	<i>8</i>
<i>K306 multiple emitters option</i>	<i>8</i>
<i>K308 direction finding option</i>	<i>8</i>
<i>K309 2D map import option</i>	<i>8</i>
<i>K501 extended sequencer option for R&S®SMW-B10</i>	<i>8</i>
<i>K502 wideband extended sequencer option for R&S®SMW-B9</i>	<i>8</i>
<i>K315 pulse-on-pulse simulation</i>	<i>9</i>
<i>K350 dynamic frequency selection (DFS) option</i>	<i>9</i>
Minimum configuration	10
Pulse sequencing.....	11
Pulses	11
Inter pulse modulation (IPM)	12
Modulation on pulse (MOP)	13
Data sources	14
Sequences	15
Waveforms and imported signals.....	15
Scenarios	16
Enhanced pulse sequencing.....	17
Pulses	17
Inter pulse modulation (IPM)	17
Modulation on pulse (MOP)	17
Sequences	18
Waveforms and imported signals.....	18
Emitters	18
Antenna patterns	19
Antenna scans.....	21
Scenarios	22
Radar platforms.....	24
Platform properties	24

Movements	25
Scenarios	25
Multiple emitters.....	27
Scenarios	27
Direction finding.....	28
Receivers	28
Scenarios	29
2D map import.....	30
Extended sequencing for R&S®SMW-B10	31
Wideband extended sequencing for R&S®SMW-B9.....	32
Pulse-on-pulse simulation	33
Dynamic frequency selection (DFS).....	34
National standards.....	34
USA.....	34
Europe.....	35
Japan	35
Korea.....	36
China.....	36
PDW report generation	37
Path loss compensation.....	37
Supported generators.....	37
Remote control.....	38
PC hardware requirements	38
Ordering information	39

Definitions


General

Product data applies under the following conditions:

- Three hours storage at ambient temperature followed by 30 minutes warm-up operation
- Specified environmental conditions met
- Recommended calibration interval adhered to
- All internal automatic adjustments performed, if applicable

Specifications with limits

Represent warranted product performance by means of a range of values for the specified parameter. These specifications are marked with limiting symbols such as $<$, \leq , $>$, \geq , \pm , or descriptions such as maximum, limit of, minimum. Compliance is ensured by testing or is derived from the design. Test limits are narrowed by guard bands to take into account measurement uncertainties, drift and aging, if applicable.



Specifications without limits

Represent warranted product performance for the specified parameter. These specifications are not specially marked and represent values with no or negligible deviations from the given value (e.g. dimensions or resolution of a setting parameter). Compliance is ensured by design.

Typical data (typ.)

Characterizes product performance by means of representative information for the given parameter. When marked with $<$, $>$ or as a range, it represents the performance met by approximately 80 % of the instruments at production time. Otherwise, it represents the mean value.

Nominal values (nom.)

Characterize product performance by means of a representative value for the given parameter (e.g. nominal impedance). In contrast to typical data, a statistical evaluation does not take place and the parameter is not tested during production.

Measured values (meas.)

Characterize expected product performance by means of measurement results gained from individual samples.

Uncertainties

Represent limits of measurement uncertainty for a given measurand. Uncertainty is defined with a coverage factor of 2 and has been calculated in line with the rules of the Guide to the Expression of Uncertainty in Measurement (GUM), taking into account environmental conditions, aging, wear and tear.

Device settings and GUI parameters are indicated as follows: "parameter: value".

Typical data as well as nominal and measured values are not warranted by Rohde & Schwarz.

Notations and abbreviations

Option names consist of the instrument name and a designation.

For example, R&S®SMW-K300 refers to pulse sequencing. This means that R&S®SMW-K300 is the pulse sequencing option for R&S®SMW200A; R&S®SMBVB-K300 is the pulse sequencing option for R&S®SMBV100B.

If there is no further differentiation necessary, the options are abbreviated for example by K300, which summarizes the options R&S®SMW-K300, R&S®SMBV-K300, R&S®SMBVB-K300 and R&S®SGT-K300.

Introduction

The R&S®Pulse Sequencer software and its respective software options for Rohde & Schwarz signal generators have been specifically developed for easy generation of pulsed signals.

The R&S®Pulse Sequencer software together with a K300 option allows generating pulsed signals with basic modulation schemes. Signals with simple pulses, pulse trains and repetition of pulses can be generated. In addition, pulse trains with different pulses and pulse breaks can be generated sequentially. The K301 option allows to make use of various control elements for sequencing applications. In addition, influences of antenna diagrams and antenna scans can be considered. Pulse sequences, antenna diagrams and antenna scans can be combined to an emitter. For scenario simulation, multiple emitters together with a receiver can be placed on a 2D map.

The R&S®SMW-K302 radar platforms option, which is available for R&S®SMW-B9, allows the simulation of platforms, on which several emitters can be placed and positioned. Together with the K304 moving emitters and receiver option, complex scenarios with real world vehicles can be simulated.

The R&S®SMW-K304 moving emitters option in combination with the R&S®SMW-B9 wideband baseband generator option enables moving emitters and receiver in map based scenario types providing a sophisticated waypoint interface as well as real world kinematics.

The R&S®SMW-K306 multiple emitters option in combination with the R&S®SMW-B9 wideband baseband generator option enables interleaving multiple emitter signals into a single output signal using a priority based dropping algorithm in order to increase emitter and pulse density for a given hardware setup.

If the K309 2D map import option is installed, the user can import georeferenced maps and perform positioning and movement traces based on real world longitude and latitude coordinates rather than relative ones that are based on the receiver position.

The K308 direction finding option enhances the software by providing a scenario type for direction finding applications. A receiver model which can have multiple antennas with individual positioning is introduced and individual receive signals for each antenna port are calculated.

The K501 extended sequencing option for R&S®SMW-B10 and the K502 wideband extended sequencing option for R&S®SMW-B9 use a PDW based signal generation approach, which leads to dramatically increased simulation time and reduced calculation time.

This document describes the software options working with the PC-based R&S®Pulse Sequencer software for the following instruments:

- R&S®SMW200A
- R&S®SMBV100A
- R&S®SMBV100B
- R&S®SGT100A

The R&S®Pulse Sequencer (DFS) software and its respective software option for the Rohde & Schwarz signal generators have been specifically developed for generation of radar signals as specified by the FCC, ETSI or the Telec T403 standard. This document describes the software options for dynamic frequency selection (DFS) working with the PC-based R&S®Pulse Sequencer (DFS) software for the following instruments:

- R&S®SMW200A
- R&S®SMBV100A
- R&S®SMBV100B
- R&S®SGT100A
- R&S®SMU200A
- R&S®SMJ100A

I/Q baseband generators and memory size

Any waveform produced with the R&S®Pulse Sequencer software or R&S®Pulse Sequencer (DFS) software requires an I/Q baseband generator with ARB installed on the respective Rohde & Schwarz vector signal generator.

For the R&S®SMW200A (standard model)	R&S®SMW-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time), 120 MHz RF bandwidth
	The following enhancement options can be added to the R&S®SMW-B10 option:	
	R&S®SMW-K511	ARB memory extension to 512 Msample
	R&S®SMW-K512	ARB memory extension to 1 Gsample
For the R&S®SMW200A (wideband model)	R&S®SMW-K522	bandwidth extension to 160 MHz RF bandwidth
	R&S®SMW-B9	wideband baseband generator with ARB (256 Msample) and digital modulation (real-time), 500 MHz RF bandwidth
	The following enhancement options can be added to the R&S®SMW-B9 option:	
	R&S®SMW-K515	ARB memory extension up to 2 Gsample
For the R&S®SMU200A	R&S®SMW-K525	baseband extension to 1 GHz RF bandwidth
	R&S®SMW-K527	baseband extension to 2 GHz RF bandwidth
	R&S®SMU-B9	baseband generator with ARB (128 Msample) and digital modulation (real-time)
For the R&S®SMJ100A	R&S®SMU-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time)
	R&S®SMU-B11	baseband generator with ARB (16 Msample) and digital modulation (real-time)
	R&S®SMJ-B9	baseband generator with ARB (128 Msample) and digital modulation (real-time)
	R&S®SMJ-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time)
For the R&S®SMBV100A	R&S®SMJ-B11	baseband generator with ARB (16 Msample) and digital modulation (real-time)
	R&S®SMJ-B50	baseband generator with ARB (64 Msample)
	R&S®SMJ-B51	baseband generator with ARB (16 Msample)
	R&S®SMBV-B10	baseband generator with digital modulation (real-time) and ARB (32 Msample), 120 MHz RF bandwidth
	R&S®SMBV-B10F	baseband generator for GNSS with high dynamics, digital modulation (real-time) and ARB (32 Msample), 120 MHz RF bandwidth
	R&S®SMBV-B51	baseband generator with ARB (32 Msample), 60 MHz RF bandwidth
	The following enhancement options can be added to the R&S®SMBV-B51 option:	
	R&S®SMBV-K521	bandwidth extension to 120 MHz RF bandwidth
	R&S®SMBV-K522	bandwidth extension to 160 MHz RF bandwidth
	The following enhancement options can be added to the R&S®SMBV-B10/-B10F/-B51 options:	
R&S®SMBV-K511	ARB memory extension to 256 Msample	
R&S®SMBV-K512	ARB memory extension to 512 Msample	
R&S®SMBV-K522	bandwidth extension to 160 MHz RF bandwidth	
For the R&S®SMBV100B	Base unit includes the ARB baseband generator (64 Msample, 120 MHz RF bandwidth)	
	R&S®SMBVB-K523	baseband extension to 240 MHz RF bandwidth
	R&S®SMBVB-K524	baseband extension to 500 MHz RF bandwidth
	R&S®SMBVB-K511	ARB memory extension to 256 Msample
	R&S®SMBVB-K512	ARB memory extension to 1 Gsample
For the R&S®SGT100A	R&S®SMBVB-K513	ARB memory extension to 2 Gsample
	R&S®SGT-K510	baseband generator with 32 Msample, 60 MHz RF bandwidth
	R&S®SGT-K511	extension to 256 Msample
	R&S®SGT-K512	extension to 1 Gsample
	R&S®SGT-K521	extension to 120 MHz RF bandwidth
R&S®SGT-K522	extension to 160 MHz RF bandwidth	

R&S®SMW-B9, R&S®SMU-B9, R&S®SMJ-B9 are referred to as B9,

R&S®SMW-B10, R&S®SMU-B10, R&S®SMJ-B10, R&S®SMBV-B10 are referred to as B10,

R&S®SMU-B11 and R&S®SMJ-B11 are referred to as B11.

For R&S®SMBV100A, it is required to install the R&S®SMBV-B92 option (hard disk).

The K300/K301/K302/K304/K306/K308/K309 and K501/K502 options require the external R&S®Pulse Sequencer software for signal generation.

The K350 option requires the external R&S®Pulse Sequencer (DFS) software for waveform generation.

Related documents

This document contains the functional specifications of the PC-based software R&S®Pulse Sequencer and R&S®Pulse Sequencer (DFS).

For instrument-specific signal performance data such as ACLR or EVM, see the data sheets of the respective Rohde & Schwarz instruments:

R&S®SMW200A:	PD 3606.8037.22
R&S®SMBV100A:	PD 5214.1114.22
R&S®SMBV100B:	PD 3607.8201.22
R&S®SGT100A:	PD 3607.0217.22
R&S®SMU200A:	PD 0758.0197.22
R&S®SMJ100A:	PD 5213.5074.22

Key features

K300 pulse sequencing option

- ARB based signal generation and multi segment waveform sequencing
- Pulse shape definition with rise and fall time, droop, ripple, overshoot
- Modulation on pulse with all major formats like chirps, Barker codes, polyphase codes, PSKs, AM, FM
- Single pulse, pulse train generation with repetition count per pulse
- Inter pulse modulation of amplitude, phase, frequency, etc. values from pulse to pulse
- Internal and external (plugins) data sources for modulation
- Import of waveform files for sequencing with repetition count

K301 enhanced pulse sequencing option

- ARB based signal generation and multi segment waveform sequencing
- Single pulse and pulse train generation with repetition count per pulse
- Powerful sequencing with loops, nested loops, subsequences and overlays
- Antenna diagram definition and antenna scan definition
- Antenna diagrams like pencil beams, cosecans beams, Gaussian, user defined, phased array antenna diagrams
- Antenna scan types like helical scans, circular scans, conical scans
- Emitter definition by waveforms, antenna diagram, antenna scan, attitude information, EIRP and carrier frequency
- Receiver definition by antenna diagram, antenna scan and attitude information
- Calculation of signal considering one-way free space propagation according to emitter and receiver location on a 2D map
- Import of R&S®WinIQSIM2™ or customer waveforms for interference generation on the 2D map

K302 radar platforms option

- Simulation of real live vehicles, that carry multiple radar emitters on a common movable platform
- All emitters carried by a platform can be configured for use of mode changes as well

K304 moving emitters option

- Enhances the localized and direction finding scenario types by movement profiles for emitters and receivers
- Predefined line and arc movements, traces as well as waypoint import interface for complex movement traces
- WGS84 waypoint interface and import of NMEA waypoints
- Import of Google Earth and Google Maps .kml files
- East-North-Up (ENU) 2D vector trajectory interface (line, arc) for automatic waypoint generation
- Motion interface for dynamics input (velocity vector or velocity magnitude) in ENU and WGS84
- User-definable and predefined vehicle description files for land vehicles, ships, aircraft and spacecraft
- Smoothing of waypoints using vehicle description files

K306 multiple emitters option

- Allows interleaving of multiple PDW lists in the PDW list scenario type and interleaving of emitters in emitters collection, localized emitters and direction finding scenario types into a single output file using a priority scheme for pulse dropping.

K308 direction finding option

- Enhances the K300/K301 features by a direction finding scenario type
- Direction finding receiver definition with up to 20 antennas with individual positioning and pointing
- Individual signal generation for each receive antenna

K309 2D map import option

- Allows the import of georeferenced map files (.geoTiff)
- Positioning can be performed using real world longitude and latitude coordinates
- 2D and 3D visualization of map content

K501 extended sequencer option for R&S®SMW-B10

- Real-time signal generation for unmodulated rectangular CW pulses and pulses with linear frequency modulation or Barker codes. Other pulse shapes are realized as sequencer based ARB playback with min. calculation time and memory requirements
- Very long simulation time and dramatically decreased calculation times

K502 wideband extended sequencer option for R&S®SMW-B9

- Real-time signal generation for unmodulated rectangular CW pulses and pulses with linear frequency modulation or Barker codes. Other pulse shapes are realized as sequencer based ARB playback with min. calculation time and memory requirements
- Very long simulation time and dramatically decreased calculation times

K315 pulse-on-pulse simulation

- Allows the usage of SMW-B15 coprocessor boards to simulate up to 6 true parallel instances of the extended sequencer in a single instrument. The individual sequencers allow pulse-on-pulse simulation of time overlapping signals.

K350 dynamic frequency selection (DFS) option

- Supported standards for Europe, the US, Korea, China and Japan

Minimum configuration

The following minimum required configuration for the instruments is listed hereafter for K300, K301 and K350 options.

R&S®SMW200A (standard model)	
R&S®SMW200A	vector signal generator
R&S®SMW-B13	signal routing and baseband main module, one I/Q path to RF
R&S®SMW-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time), 120 MHz RF bandwidth
R&S®SMW-B103	frequency option: 100 kHz to 3 GHz
R&S®SMW-B106	frequency option: 100 kHz to 6 GHz
R&S®SMW200A (wideband model)	
R&S®SMW200A	vector signal generator
R&S®SMW-B13XT	wideband baseband main module, two I/Q paths to RF
R&S®SMW-B9	wideband baseband generator with ARB (256 Msample) and digital modulation (real-time), 500 MHz RF bandwidth
R&S®SMW-B103	frequency option: 100 kHz to 3 GHz
R&S®SMW-B106	frequency option: 100 kHz to 6 GHz
R&S®SMBV100A	
R&S®SMBV100A	vector signal generator
R&S®SMBV-B51	baseband generator with ARB (32 Msample), 60 MHz RF bandwidth
R&S®SMBV-B92	hard disk (removable)
R&S®SMBV-B103	frequency option: 100 kHz to 3.2 GHz
R&S®SMBV-B106	frequency option: 100 kHz to 6 GHz
R&S®SMBV100B	
R&S®SMBV100B	vector signal generator
R&S®SMBVB-B103	frequency option 8 kHz to 3 GHz
R&S®SGT100A	
R&S®SGT100A	vector signal generator
R&S®SGT-K510	ARB baseband generator, 32 Msample, 60 MHz RF bandwidth
R&S®SGT-KB106	frequency extension to 6 GHz
R&S®SMU200A	
R&S®SMU200A	vector signal generator
R&S®SMU-B13	baseband main module
R&S®SMU-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time)
R&S®SMU-B106	frequency option: 100 kHz to 6 GHz
R&S®SMJ100A	
R&S®SMJ100A	vector signal generator
R&S®SMJ-B13	baseband main module
R&S®SMJ-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time)
R&S®SMJ-B106	frequency option: 100 kHz to 6 GHz

If two I/Q baseband generators are installed and two pulse sequencing waveforms generated with the R&S®Pulse Sequencer software are to be output simultaneously, two corresponding software options (e.g. K300) must also be installed (e.g. R&S®SMW-K300 for an R&S®SMW200A). If only one R&S®SMW-K300 option is installed and the pulse sequencing waveform is loaded in one I/Q baseband generator, the other I/Q baseband generator is disabled for pulse sequencing waveforms. However, a software option is not tied to a specific I/Q baseband generator.

For R&S®SMW-K350, R&S®SMBV-K350, R&S®SMBVB-K350 and R&S®SGT-K350 options, the required bandwidth extension options depend on the supported bandwidth of the DUT.

The following minimum configuration for R&S®SMW200A is listed hereafter for a direction finding scenario with K300, K301 and K308 options. It allows the simulation of 2 RX antennas with a single emitter.

R&S®SMW200A	
R&S®SMW200A	vector signal generator
R&S®SMW-B13T	signal routing and baseband main module, one I/Q path to RF
R&S®SMW-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time), 120 MHz RF bandwidth
R&S®SMW-B10	baseband generator with ARB (64 Msample) and digital modulation (real-time), 120 MHz RF bandwidth
R&S®SMW-B103/ -B1003	frequency option: 100 kHz to 3 GHz
R&S®SMW-B203/ -B2003	frequency option: 100 kHz to 3 GHz

Pulse sequencing

For R&S®SMW-K300, R&S®SMBV-K300, R&S®SMBVB-K300, R&S®SGT-K300

Pulses

Parameter type		
Timing		
Envelope types		custom envelope, standard profile
Timing related to % amplitude		0/100, voltage 10/50/90, power 10/50/90
Rising edge		0 s to 3600 s
Falling edge		0 s to 3600 s
Standard edge types		linear, cosine, root cosine, sqrt
Width		0 s to 3600 s
Custom envelope		list based, equation based
Level		
Attenuation top power		0 dB to 100 dB
Attenuation base power		0 dB to 100 dB
Droop		0 % to 50 % power
Overshoot		0 % to 50 % voltage
Overshoot decay parameter		1 to 100
Ripple		0 % to 50 % voltage
Ripple frequency		0 Hz to 300 MHz
MOP		
Available modulation types		see MOP section
Restrict MOP to certain area of pulse		no restriction, pulse width, exclude time (at beginning, at end), level threshold (rising edge, falling edge)
Marker		
Number of markers		M1 to M4 (depending on generator type)
Marker types		rise time, width, fall time, restart, gate, pre, post

Remark:

For an extended on/off ratio the software option R&S®SMW-K22 pulse modulator can be installed. For technical details, please refer to the R&S®SMW200A data sheet (PD 3606.8037.22).

Inter pulse modulation (IPM)

Inter pulse modulation varies pulse parameters from pulse to pulse. The IPM mechanism is used to generate PRI stagger or frequency hopping, for example. The output of multiple IPM profiles can be combined.

Types of inter pulse modulation profiles		
Steps		
Start		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Increment		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Steps		1 to 10000
Burst length		1 to 1000
Burst period		1 ns to 10^9 s
List		
Parameters per entry		value, repetitions
Firing order		sequencing of list entries using text based macros
Number of entries		8000
Value		$-1 \cdot 10^9$ to $1 \cdot 10^9$
List base		repetitions/time
Repetitions		1 to 10^9
Time		1 ns to 10^9 s
Waveform		
Type		ramp, sine, triangular
DC offset		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Phase offset		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Peak to peak		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Period time		1 ns to 10^9 s
Pulse count		1 to 10^9
Interpolated shape		
Parameters per entry		value
Number of entries		8000
Value		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Period time		1 ns to 10^9 s
Pulse count		1 to 10^9
Interpolation		linear, none (s/h)
Binomial		
Value 1		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Probability		0.00% to 100%
Value 2		$-1 \cdot 10^9$ to $1 \cdot 10^9$
Unit of affected parameter		none, time in s, frequency in Hz, level in dB, phase in °, percent in %
Available parameters		
Level		overshoot in %, offset in dB, attenuation top in dB, ripple in %, droop in %, attenuation base in dB, ripple frequency in Hz
Modulation		AM modulation depth in %, FM deviation in Hz, FM frequency in Hz, chirp deviation in Hz, AM frequency in Hz
Timing		rise time in s, pulse width in s, delay in s, fall time in s, PRF in Hz, PRI in s
Phase		offset in °
Frequency		offset in Hz
Other		custom variables that can be used in equation parsers (sequencing, envelope, MOP, report generation)

Modulation on pulse (MOP)

The modulation on pulse describes the modulation used within a pulse. The R&S®Pulse Sequencer software supports a wide range of built-in MOP types. Custom MOP can be added by plugins.

MOP types		
AM		
Types		standard, LSB, USB, LSB+USB
Frequency		1 mHz to 1 GHz
Modulation depth		0 % to 100 %
ASK		
Modulation depth		0 % to 100 %
Inverted		yes, no
Symbol rate		1 Hz to 1 GHz
Data source		yes
Baseband filter		no
AM step		
Values per step		duration, level
Number of entries		1024
FM		
Frequency		1 mHz to 1 GHz
Deviation		1 mHz to 1 GHz
FSK		
Type		2/4/8/16/32/64 FSK
Deviation		1 mHz to 1 GHz
Symbol rate		1 Hz to 1 GHz
Data source		yes
Baseband filter		no
FM step		
Values per step		duration, frequency
Number of entries		1024
MSK		
Symbol rate		1 Hz to 1 GHz
Data source		yes
Baseband filter		no
Linear chirp		
Types		up, down, sine, triangular
Deviation		1 Hz to 1 GHz
Chirp (equation-based)		
Polynomial chirp		
Values		term, coefficient
Coefficient range		$-1 \cdot 10^{22}$ to $1 \cdot 10^{22}$
Number of entries		1024
Barker		
Codes		R3, R4a, R4b, R5, R7, R11, R13
Transition time (const. envelope)		0 % to 50 %
Polyphase		
Codes		Frank, P1, P2, P3, P4
Length M		1 to 64
Custom phase		
Values		phase in °
Number of entries		1024

BPSK		
Types		standard, constant envelope
Symbol rate		auto fit to PW, 1 Hz to 1 GHz
Phase change		0.1° to 180°
Transition		linear, cosine
Transition duration		0 % to 50 %
Data source		yes
Baseband filter		yes
QPSK		
Types		standard, OQPSK, DQPSK, SOQPSK-A, SOQPSK-B, SOQPSK-TG
Symbol rate		1 Hz to 1 GHz
Data source		yes
Baseband filter		yes
8PSK		
Symbol rate		1 Hz to 1 GHz
Data source		yes
Baseband filter		yes
QAM		
Type		16/32/64/128/256 QAM
Symbol rate		1 Hz to 1 GHz
Data source		yes
Baseband filter		yes
White noise		
Bandwidth		1 Hz to 1 GHz
Baseband filter	any filter can be used with the MOP types using baseband filters	
Filter types		none, rectangular, cosine, root cosine, gaussian, low pass, gauss (FSK)
Filter parameter		
Filter parameter	cosine, root cosine (filter parameter α)	0.05 to 1.00
	gaussian (filter parameter $B \times T$)	0.15 to 2.50
Length		8 to 512
Bandwidth	rectangular, cosine, root cosine, low pass	1 Hz to 1 GHz
Coding	not all coding methods can be used with every type of modulation	none, differential, gray, differential and gray
Data sources		PRBS: 7, 9, 11, 15, 16, 20, 21, 23, All0, All1, pattern (length: 1 bit to 64 bit), data lists

Data sources

Data sources deliver binary data to certain modulation on pulse (MOP) profiles, such as ASK, BPSK or QPSK.

Types of data sources		
PRBS		
Mode		PRBS: 7, 9, 11, 15, 16, 20, 21, 23
Bits		1 to infinite
Pattern		
Mode		All0, All1, 1010, Barker R3, R4a, 4b, 5, 7, 11, 13
Bits		1 to 1000
User		
Data types		binary, hexadecimal, ASCII text

Sequences

A sequence combines multiple pulses or waveforms to the final output signal.

Sequencing element		
Pulse		
Repetition count		fixed, randomly selected, auto set by duration
IPM		static, any combination of available IPM profiles
Marker 1 to 4		first, last, all variable comparison against value (<, >, =, !=)
Delta frequency		-1 GHz to +1 GHz
Delta level		-100 dB to +30 dB
Phase		-180° to +180°
PRI		pulse duration to 10 ⁹ s
Delay		0 to (PRI – pulse duration)
Wave		
Repetition count		fixed
IPM		static, any combination of available IPM profiles
Marker 1 to 4		from waveform
Delta frequency		-1 GHz to +1 GHz
Delta level		-100 dB to +30 dB
Phase		-180° to +180°
PRI		wave duration to 10 ⁹ s
Delay		0 to (PRI – wave duration)
Global parameters		
Number of line items		1 to 256
Phase mode		absolute, continuous, memory

Waveforms and imported signals

Waveforms can be used in sequences if custom I/Q data shall be used instead of a computed pulse envelope or MOP. Using Rohde & Schwarz waveform files may require additional licensing options on the baseband generator.

Parameter type		
CW		
Multitone		
Tones		2 to 1024
Spacing		100 Hz to 10 MHz
AWGN		
Bandwidth		0 Hz to 300 MHz
PDW data		
Format		custom PDW data with import template
I/Q waveform		
Import from formats		
Rohde & Schwarz	.wv	ARB waveform files (Rohde & Schwarz)
	.iqtar	I/Q tar archive files
	.riq	Rohde & Schwarz PR100 files
Custom		ASCII; I/Q delimited in columns
		binary (integer, real)
	.mat	complex vector
	.wav	audio waveforms using the left channel for I and the right channel for Q
PDW		text based custom PDW data in combination with an import template file
Maximum file size		10 Gbyte

Scenarios

The following scenario types are available.

Scenario type		
Single sequence		
Sequence		1 single sequence
Output		ARB waveform, multi-segment waveform segment
Clock rate		auto (oversampling 1 to 1000) manual (1 Hz to 2.4 GHz)
Duration		auto fixed duration (1 μ s to 3600 s)
Markers		sequence markers M1 at scenario start
Threshold for pulse generation		-100 dB to 0 dB
Waveform sequence		
Sequence		1 single sequence
Output		ARB waveform, multi-segment waveform segment
Clock rate		auto (oversampling 1 to 1000) manual (1 Hz to 2.4 GHz)
Duration		auto fixed duration (1 μ s to 3600 s)
Markers		sequence markers M1 at scenario start
Threshold for pulse generation		-100 dB to 0 dB
Sequences (collection)		
Sequences		1 to 64
Output		ARB waveform, multi-segment waveform segment
Clock rate		auto (oversampling 1 to 1000) manual (1 Hz to 2.4 GHz)
Duration		auto fixed duration (1 μ s to 3600 s)
Markers		sequence markers M1 at scenario start
Threshold for pulse generation		-100 dB to 0 dB
PDW list (collection)		
PDW file		1 waveform object with type PDW data
Number of PDW files		1 to 256 (1 at a time or interleaved with R&S [®] SMW-K306)
Absolute level		-130 dBm to +30 dBm
Frequency		0 Hz to 44 GHz
Output		extended sequencer file
Clock rate		auto
Duration		auto
Markers		M1 at scenario start, pulse
Threshold for pulse generation		-100 dB to 0 dB

Enhanced pulse sequencing

For R&S®SMW-K301, R&S®SMBV-K301, R&S®SMBVB-K301, R&S®SGT-K301

The K301 option is only available as add-on to the K300 option. Therefore, each K301 option requires a K300 option. The complexity of a data repository has to be set to advanced K300/K301 mode.

Pulses

The following settings are available in addition to the features provided by K300 option.

Parameter type		
Timing		
Custom envelope types		value list, equation

Inter pulse modulation (IPM)

The following IPM profiles can be applied to pulse parameters in addition to the IPM profiles provided by the K300 option.

Types of inter pulse modulation profiles		
Equation		
Random list		
Burst length		1 to 8192
Burst period		1 ns to 10 ⁹ s
Avoid reuse		yes, no
Values per entry		value
Number of entries		1024
Value		-1 · 10 ⁶ to 1 · 10 ⁶
Random steps		
Min.		-1 · 10 ⁶ to 1 · 10 ⁶
Max.		-1 · 10 ⁶ to 1 · 10 ⁶
Step size min.		0 to 10 ⁶
Step size max.		0 to 10 ⁶
Periodicity count		0 to 4096
Random		
Distribution		uniform, normal, U
Min.		-1 · 10 ⁹ to 1 · 10 ⁹
Max.		-1 · 10 ⁹ to 1 · 10 ⁹
Step		-1 · 10 ⁹ to 1 · 10 ⁹
Plugin		
Format		32 bit Windows .dll, API specified in user manual

Modulation on pulse (MOP)

The following MOP types are available in addition to the MOP types provided by the K300 option.

Types of modulation on pulse		
Plugin		
Data source		yes
Baseband filter		yes

Sequences

The following sequencing element types are available in addition to the ones provided by the K300 option.

Element types		
Loop		
Repetition count		fixed, randomly selected
Filler		
Signal		blank, CW, hold last sample
Mode		duration, time synchronization
Time		fixed, equation
Overlay		
Duration		0 s to 10 ⁹ s
Sub sequence		
Repetition count		1
Global parameters		
Nesting level		0 to 6
Number of line items		1 to 256

Waveforms and imported signals

The following waveform types are available in addition to the ones provided by the K300 option.

Parameter type		
Background emitters		
Count		1 to 255
Bandwidth		1 kHz to 240 MHz
Duration		100 μ s to 1 s
Pulse width range		100 ns to 1 s
PRI/PW ratio		1 to 1000
Level range		0 dB to 90 dB

Emitters

The following emitter properties are available.

Property types		
Emitter		
EIRP		-200 dBm to +200 dBm
Frequency		1 kHz to 44 GHz
Number of modes per emitter		32
Number of beams per mode		32
Modes		
Antenna pattern		1 per mode
Scan type		1 per mode
Beams		
Active		yes, no
Sequence		1 per beam
Frequency offset		-100 MHz to +100 MHz
Beam offset elevation		-180° to +180°
Beam offset azimuth		-180° to +180°

Antenna patterns

The following antenna patterns can be applied to emitters and receiver.

Antenna types		
Dipole		
Cardioid		
Exponent		1 to 20
Parabolic		
Frequency		1 MHz to 100 GHz
Bandwidth		1 MHz to 100 GHz
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
Diameter		0.05 m to 100 m
Gaussian		
Frequency		no
Bandwidth		no
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
HPBW Azimuth		0.1° to 60°
HPBW elevation		0.1° to 60°
Sin(x)/x		
Frequency		1 MHz to 100 GHz
Bandwidth		1 MHz to 100 GHz
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
HPBW		0.1° to 45°
HPBW		0.1° to 45°
Pyramidal horn		
Frequency		1 MHz to 100 GHz
Bandwidth		1 MHz to 100 GHz
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
Length X		0.01 m to 100 m
Length Z		0.01 m to 100 m
Cosecant squared		
Frequency		no
Bandwidth		no
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
HPBW		0.01° to 30°
Theta 1		0.01° to 90°
Theta 2		0.01° to 90°
Planar phased array		
Frequency		1 MHz to 100 GHz
Bandwidth		1 MHz to 100 GHz
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
Aperture distribution		uniform, parabolic, cosine, cosine squared, cos^N, triangular, Hamming, Hann
Antenna element type		omnidirectional, cosine
Elements X		1 to 1000
Elements Z		1 to 1000
Spacing X		0.001 m to 1 m
Spacing Z		0.001 m to 1 m
Pedestal		0 to 1 (parabolic, cosine, cosine squared, triangular, Hamming, Hann aperture distribution)
cos^N		2 to 10 (cos^N aperture distribution)

Custom phased array		
Frequency		1 MHz to 100 GHz
Bandwidth		1 MHz to 100 GHz
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
Aperture distribution		uniform, parabolic, cosine, cosine squared, cos ^N , triangular, Hamming, Hann
Antenna element type		omnidirectional, cosine
Geometry		uniform rect, uniform linear, uniform hex, circular planar
Uniform rect		
Elements		1 to 1000
Elements Z		1 to 1000
Spacing X		0.001 m to 1 m
Spacing Z		0.001 m to 1 m
Lattice		rectangular, triangular
Uniform linear		
Elements		1 to 1000
Spacing		0.001 m to 1 m
Uniform hex		
Elements/side		1 to 50
Spacing		0.001 m to 1 m
Circular planar		
Radius		1 to 50
Spacing		0.001 m to 1 m
Lattice		rectangular, triangular
Import from file		
Supported formats		.csv (comma separated values) .ffe (FEKO far field) .ant_pat (Rohde & Schwarz pattern file) .tsv (Antenna Magnus) .ffd (Ansys HFSS)
Frequency		yes
Bandwidth		yes
Simulate back lobe		yes
Custom		
Frequency		no
Bandwidth		no
Simulate back lobe		yes
Back lobe attenuation		0 dB to 100 dB
HPBW XY		0.01° to 90°
HPBW YZ		0.01° to 90°
Side lobe level		0 dB to 100 dB
Roll off factor		0 dB to 100 dB
Side lobe scale		0.2 to 5

Antenna scans

The following scan types can be applied to emitters and receivers. Certain scan types can be used as electronic scans for phased array antennas.

Scan types		
Circular		
Scan rate		0.01 rpm to 1000 rpm
Direction		CW, CCW
Nodding		on/off
Elevation rate		0.01°/s to 2000°/s
Elevation angle		0.01° to 90°
Palmer scan		on/off
Scan rate		100 mHz to 1 kHz
Squint angle		0.05° to 45°
Sector		
Electronic scan		on/off
Sector width		0.01° to 360°
Scan rate		0.01 rpm to 1000 rpm
Unidirectional		on/off
Flyback time		0 s to 1 s (with unidirectional = on)
Nodding		on/off
Elevation rate		0.01°/s to 2000°/s
Elevation angle		0.01° to 90°
Palmer scan		on/off
Scan rate		100 mHz to 1 kHz
Squint angle		0.05° to 45°
Raster		
Electronic scan		on/off
Raster width		0.01° to 180°
Bar width		0.01° to 180°
Scan rate		0.01 rpm to 10000 rpm
Bar count		1 to 1000
Retrace time		0 s to 1 s
Unidirectional		on/off
Flyback time		0 s to 1 s (with unidirectional = on)
Bar transition time		0 s to 1 s (with unidirectional = off)
Palmer scan		on/off
Scan rate		100 mHz to 1 kHz
Squint angle		0.05° to 45°
Conical		
Electronic scan		on/off
Scan rate		10 mHz to 1 kHz
Direction		CW, CCW
Squint angle		0.01° to 30°
Helical		
Electronic scan		on/off
Scan rate		0.01°/s to 1000°/s
Turns		1 to 1000
Step angle		0.01° to 30°
Retrace time		0 s to 1 s
Direction		CW, CCW
Spiral		
Electronic scan		on/off
Rounds		1 to 100
Round time		1 μs to 1 s
Angular step		0.1° to 5°
Retrace time		0 s to 1 s
Direction		CW, CCW
Lobe switching		
Electronic scan		on/off
Lobes		2, 4
Squint angle		0.05° to 15°
Dwell time		1 μs to 1 s
Direction		vertical, horizontal with 2 lobes only
Rotation		CW, CCW with 4 lobes only

Sine		
Electronic scan		on/off
Width		1.00° to 180°
Height		1.00° to 90°
Scan rate		0.01 rpm to 1000 rpm
Direction		CW, CCW
Unidirectional		on/off
Invert up/down scan		on/off
Custom (List of entries)		
Electronic scan		on/off
Azimuth		-180° to +180°
Elevation		-90° to +90°
Dwell time		0 s to 3600 s
Interpolate to next		true/false (move or jump to next coordinate)
Transition time		0 s to 3600 s (if interpolate to next is true, this parameter resembles the time for the transition to the next coordinate)
Lissajous		
Electronic scan		on/off
Amplitude X		0.01° to 45°
Amplitude Z		0.01° to 45°
Frequency		0.01 Hz to 1000 Hz
Freq X ratio		1 to 10
Freq Z ratio		1 to 10
Phase X		0.00° to 360°
Phase Z		0.00° to 360°

Scenarios

The following emitter-based scenario types are available in addition to the scenario types provided by K300.

Scenario type		
Single emitter		
Yaw		0° to 360°
Pitch		-90° to +90°
Roll		0° to 360°
Output		ARB waveform, multisegment waveform segment
Clock rate		auto (oversampling 1 to 1000) manual (1 Hz to 2.4 GHz)
Duration		auto fixed duration (1 µs to 3600 s)
Markers		scenario markers M1 at scenario start
Threshold for pulse generation		-100 dB to 0 dB
Emitters (collection)		
Emitter		sequence, antenna pattern, antenna scan, operation modes, beams
Number of emitters		1 to 64 (1 at a time) or all interleaved with R&S®SMW-K306
Frequency offset		-2 GHz to +2 GHz
Scan delay		-3600 s to +3600 s
Absolute level		-130 dBm to +30 dBm
Operation mode		static/mode changes
Yaw		0° to 360°
Pitch		-90° to +90°
Roll		0° to 360°
Output		ARB waveform, multi-segment waveform segment
Clock rate		auto (oversampling 1 to 1000) manual (1 Hz to 2.4 GHz)
Duration		auto fixed duration (1 µs to 3600 s)
Markers		scenario markers M1 at scenario start
Threshold for pulse generation		-100 dB to 0 dB

Localized emitters		
Number of platforms, emitters, interferers and background signals	definable with the R&S®Pulse Sequencer software	1 to 64
Maximum number of simultaneous playback of emitters, interferers and background signals	R&S®SMBV100A, R&S®SMBV100B, R&S®SGT100A	1 per baseband generator
	R&S®SMW200A	1 per baseband path
	R&S®SMW200A + 2 × R&S®SMW-B10 + 1 × R&S®SMW-K76	up to 4
Platform/emitter/interferer properties		
Emitter behavior		
Static configuration	static mode and beam	mode and beam (defines sequence, antenna pattern and antenna scan)
Mode changes configuration	per operation mode entry each entry consists of a mode/beam pair	mode and beam (defines sequence, antenna pattern and antenna scan) start & stop time of operation mode entry
Emitter parameters		sequence, antenna pattern, antenna scan, operation modes, beams
Interferer behavior		
Static configuration	static	antenna pattern and antenna scan
Interferer parameters		ARB waveform object, EIRP
Position mode		
Static	single static position	
East		$-1 \cdot 10^7$ m to $1 \cdot 10^7$ m
North		$-1 \cdot 10^7$ m to $1 \cdot 10^7$ m
Height		0 m to 10^5 m
Yaw		0° to 360°
Pitch		-90° to +90°
Roll		0° to 360°
Point to receiver		on/off
Steps	multiple static position steps	
Background signals properties		
Signal source		any sequence or waveform
Level at receiver origin		-100 dB to +25 dB
Frequency		1 kHz to 44 GHz
Receiver properties		
Antenna pattern		all available antenna patterns
Scan		all available antenna scans
Gain		-120 dB to +120 dB
Position mode		
Static	single static position	
Height		0 m to 10^5 m
Yaw		0° to 360°
Pitch		-90° to +90°
Roll		0° to 360°
Output		ARB waveform, multi-segment waveform segment
Clock rate		auto (oversampling 1 to 1000) manual (1 Hz to 2.4 GHz)
Duration		auto fixed duration (1 μs to 3600 s)
Markers		scenario markers M1 at scenario start
Threshold for pulse generation		-100 dB to 0 dB

Radar platforms

For R&S®SMW-K302

The K302 option is only available as add-on to the combination of the K300 and K301 options. Therefore, each K302 option requires a K300 and a K301 option.

Platform properties

The following platform properties are available.

Property types		
Emitters		
Number of emitters per platform		1 to 8
Individual emitter properties		
Static position relative to platform origin		
X		-2000 m to +2000 m
Y		-2000 m to +2000 m
Radius		0 m to 2000 m
Angle		0° to 360°
Height		-500 m to +500 m
Emitter		
Type		all available emitter types
Blank ranges	signal mutes in these sectors	start angle/stop angle 0° to 360°
Pointing direction		
Auto away from origin		on/off
Elevation		-90° to +90°
Azimuth		0° to 360°
Roll		-180° to +180°
Movements		
For movement types please refer to description of R&S®SMW-K304 in section Movements.		

Movements

For R&S®SMW-K304

This option extends the position mode for platforms, emitters and the receiver to allow motion simulation. The motion trajectories can be created via the pulse sequencer GUI or by importing text based waypoint files.

The K304 option is only available as add-on to the combination of the K300, K301, R&S®SMW-K502 and R&S®SMW-B9 options. Therefore, each K304 option requires a K300, a K301, K502, and B9 option. The complexity of a data repository has to be set to advanced K300/K301 or to K308 mode.

Scenarios

The following position options become available for platforms, emitters and receivers in addition to the scenario features already provided with the K301 or K308 options.

Position mode moving		
Trajectory line		
Start position		
East		-1 · 10 ⁷ m to 1 · 10 ⁷ m
North		-1 · 10 ⁷ m to 1 · 10 ⁷ m
Height		0 m to 10 ⁷ m
Speed		0.1 m/s to 5999 m/s
Acceleration		-100 m/s ² to +100 m/s ²
End position		
East		-1 · 10 ⁷ m to 1 · 10 ⁷ m
North		-1 · 10 ⁷ m to 1 · 10 ⁷ m
Height		0 m to 10 ⁷ m
Mode		cyclic, round trip, one way
Trajectory arc		
Start position		
East		-1 · 10 ⁷ m to 1 · 10 ⁷ m
North		-1 · 10 ⁷ m to 1 · 10 ⁷ m
Height		-1 · 10 ⁷ m to 1 · 10 ⁷ m
Speed		0.1 m/s to 5999 m/s
Angle		-360° to +360°
Center position		
East		-1 · 10 ⁷ m to 1 · 10 ⁷ m
North		-1 · 10 ⁷ m to 1 · 10 ⁷ m
Mode		cyclic, round trip, one way
Trajectory traces		
Trace point properties		
East		-1 · 10 ⁷ m to 1 · 10 ⁷ m
North		-1 · 10 ⁷ m to 1 · 10 ⁷ m
Height		0 m to 10 ⁷ m
Speed		0 m/s to 5999 m/s
Read out mode		cyclic, round trip, one way
Reference frame		WGS-84, PZ-90.11
Smoothing	trajectory smoothing based on vehicle description file	on/off
Vehicle description file		.xvd file format see user manual for format description
Attitude behavior		align to motion, constant
Yaw	only for constant	-180° to +180°
Pitch	only for constant	-90° to +90°
Roll	only for constant, align to motion	-180° to +180°
Trajectory waypoints		
Waypoint file		XTD (proprietary trajectory format), .kml, .nmea, .txt; see user manual for format description
Read out mode		cyclic, round trip, one way
Reference frame		WGS-84, PZ-90.11
Smoothing	trajectory smoothing based on vehicle description file	on/off
Vehicle description file		.xvd file format see user manual for format description

Attitude behavior		from waypoint file, align to motion, constant
Yaw	only for constant	-180° to +180°
Pitch	only for constant	-90° to +90°
Roll	only for constant, align to motion	-180° to +180°
Receiver position properties		
Latitude	geodetic reference	-90° to +90°
Longitude	geodetic reference	-180 to +180°

Multiple emitters

For R&S®SMW-K306

This option allows interleaving of multiple PDW lists in the PDW list (collection) scenario type into a single PDW file and interleaving of manually created emitters in emitters collection, localized emitters and direction finding scenario types using a priority based pulse dropping algorithm.

The K306 option is only available as add-on to the combination of the K300, K301, K502 and B9 options. Therefore, each K306 option requires K300, K301, K502, and B9 option. The complexity of a data repository has to be set to advanced K300/K301 or to K308 mode.

Scenarios

The following options become available in addition to the scenario features already provided with the K300 and K301 options.

Scenario type		
PDW list (collection)		
Max number of PDW lists		256
Max number of interleaved PDW lists	per R&S®SMW-K306 option	16 out of 256
Interleaving		on/off
Threshold for pulse generation		-100 dB to 0 dB
Enable		select/deselect for interleaving
Time offset		-1 · 10 ⁷ s to 1 · 10 ⁷ s
Priority		0 to 100 (0 corresponds to highest priority)
Level offset		-200 dB to 0 dB
Group		user created interleaving groups
Emitters (collection)		
Max number of emitters		256
Max number of interleaved emitters	per R&S®SMW-K306 option	16 out of 256
Interleaving		on/off
Threshold for pulse generation		-100 dB to 0 dB
Enable		select/deselect emitter for interleaving
Time offset		-1 · 10 ⁷ s to 1 · 10 ⁷ s
Priority		0 to 100 (0 corresponds to highest priority)
Level offset		-200 dB to 0 dB
Group		user created interleaving groups
Localized emitters		
Max number of emitters		256
Max number of interleaved emitters	per R&S®SMW-K306 option	16 out of 256
Interleaving		on/off
Threshold for pulse generation		-100 dB to 0 dB
Enable		select/deselect emitter for interleaving
Time offset		-1 · 10 ⁷ s to 1 · 10 ⁷ s
Priority		0 to 100 (0 corresponds to highest priority)
Level offset		-200 dB to 0 dB
Group		user created interleaving groups
Direction finding		
Max number of emitters		256
Max number of interleaved emitters	per R&S®SMW-K306 option	16 out of 256
Interleaving		on/off
Threshold for pulse generation		-100 dB to 0 dB
Enable		select/deselect emitter for interleaving
Time offset		-1 · 10 ⁷ s to 1 · 10 ⁷ s
Priority		0 to 100 (0 corresponds to highest priority)
Level offset		-200 dB to 0 dB
Group		user created interleaving groups

Direction finding

For R&S®SMW-K308, R&S®SMBV-K308, R&S®SMBVB-K308 and R&S®SGT-K308

The K308 option is only available as add-on to the combination of the K300 and K301 options. Therefore, each K308 option requires a K300 and a K301 option. The complexity of a data repository has to be set to K308 mode. For the simulation of more than one receive antenna, two times K308 is necessary (R&S®SMW-B9/R&S®SMW-B10). For up to four receive antennas, two K308 options and the R&S®SMW-K76 is required (R&S®SMW-B10 only).

Receivers

The following receiver properties are available.

Property types		
Model		
Type of receiver		interferometer/TDOA
Antennas		
Number of antennas per receiver		1 to 20
Individual antenna properties		
Position relative to receiver origin		
X		-2000 m to +2000 m
Y		-2000 m to +2000 m
Radius		0 m to 2000 m
Angle		0° to 360°
Height		-500 m to +500 m
Antenna pattern		
Type		all available patterns
Gain		-120 dB to +120 dB
Pointing direction		
Auto away from origin		on/off
Elevation		-90° to +90°
Azimuth		0° to 360°
Movements		
For movement types please refer to the description of R&S®SMW-K304 in section Movements.		

Scenarios

The following direction finding-based scenario types are available in addition to the scenario types provided with K300 and K301.

Scenario type		
Direction finding		
Number of emitters, interferers and background signals	definable with the R&S®Pulse Sequencer software	1 to 64
Maximum number of simultaneous waveform/signal playback ¹	R&S®SMBV100A, R&S®SMBV100B, R&S®SGT100A	1 per baseband generator
	R&S®SMW200A	1 per baseband generator
	R&S®SMW200A + 2 × R&S®SMW-B10 + 1 × R&S®SMW-K76	up to 4
Platform/emitter/interferer properties		
Emitter behavior		
Static configuration	static mode and beam	mode and beam (defines sequence, antenna pattern and antenna scan)
Mode changes configuration	per operation mode entry, each entry consists of a mode/beam pair	mode and beam (defines sequence, antenna pattern and antenna scan) start and stop time of operation mode entry
Emitter parameters		sequence, antenna pattern, antenna scan, operation modes, beams
Interferer behavior		
Static configuration	static	antenna pattern and antenna scan
Interferer parameters		ARB waveform object, EIRP
Position mode		
Static	single static position	
East		$-1 \cdot 10^7$ m to $1 \cdot 10^7$ m
North		$-1 \cdot 10^7$ m to $1 \cdot 10^7$ m
Height		0 m to 10^5 m
Yaw		0° to 360°
Pitch		-90° to +90°
Roll		0° to 360°
Point to receiver		on/off
Steps	multiple static position steps	
Background signals properties		
Signal source		any sequence or waveform
Level at receiver origin		-100 dB to +25 dB
Frequency		1 kHz to 44 GHz
Receiver properties		
Receiver		any DF receiver
Position mode		
Static	single static position	
Height		0 m to 10^5 m
Yaw		0° to 360°
Pitch		-90° to +90°
Roll		0° to 360°
Output		ARB waveform, multisegment waveform
Clock rate		auto (oversampling 1 to 1000)
		manual (1 Hz to 2.4 GHz)
Duration		sequence
		fixed duration (1 μs to 3600 s)
		one antenna scan
Markers		scenario markers
Threshold for pulse generation		M1 at scenario start -100 dB to 0 dB

¹ Number of resulting signals/waveforms depends on number of configured receive antennas, e.g. a scenario with a single emitter and four receive antennas produces four signals/waveforms.

2D map import

R&S®SMW-K309

The K309 option is only available as add-on to the combination of the K300 and K301 options. Therefore, each K309 option requires a K300 as well as a K301 option.

Parameter type		
Map file format		
Supported formats		geoTiff
Positioning parameters		
Longitude		-180° to +180°
Latitude		-90° to +90°
Altitude		-10 ⁷ m to +10 ⁷ m

Extended sequencing for R&S®SMW-B10

The R&S®SMW-K501 extended sequencing option can be used manually via sequencing lists and waveform segments or via the R&S®Pulse Sequencer software and its R&S®SMW-K300 and R&S®SMW-K301 options. In both cases, memory requirements are reduced to a minimum and playtime is increased enormously.

The extended sequencing option is mainly intended for use with pulsed signals. It is based on a sequencing file that defines the relative start time of each pulse and additionally specifies parameters such as amplitude, offset frequency and phase. Pulses with rectangular envelope and common MOP types can be entirely generated in real time and do not require a waveform segment at all.

Parameter type		
Data format		
Sequencing file		mandatory, memory shared with I/Q data and segment addresses
I/Q data file		optional
Segment addresses		optional
Memory requirements		
Sequencing file	minimum	14 byte/pulse
	maximum	26 byte/pulse
Segment addresses		16 byte/waveform segment
I/Q data file		4 byte/I/Q sample
File size		
Sequencing file	rectangular pulses, unmodulated, variable amplitude, 5 ms PRI	187 kbyte/min
	rectangular pulse, linear FM, variable FM, variable amplitude, phase and frequency, 5 ms PRI	305 kbyte/min
Setting granularity		
Time	with R&S®SMW-B10 option	5 ns
Amplitude		16 bit (voltage-based)
Phase		< 0.01°
Frequency	with R&S®SMW-B10 option	0.05 Hz
I/Q segments		
Maximum individual segments		16 777 216
Length granularity	with R&S®SMW-B10 option	32 samples
Timing		
Maximum play time	with R&S®SMW-B10 option	24 h
Minimum pulse width	with R&S®SMW-B10 option, real time	1 sample, 5 ns
	with R&S®SMW-B10 option, I/Q segment	1 samples, 5 ns
Minimum PRI/frequency switching	with R&S®SMW-B10 option	1 µs
Limitations		
Settings disabling extended sequencing data generation		non-0/100 timing, no blank signal between pulses, short PRI
Settings permitting real time pulse generation		rectangular pulse envelope, unmodulated or real time MOP
Real time MOP types		
Linear FM		up, down, triangular
Phase		Barker
Marker signals		
Number of marker signals		3
Marker types	default M1, M2, M3	active during pulse
	sequence start signal enabled	M1 active at sequence start

Wideband extended sequencing for R&S®SMW-B9

The R&S®SMW-K502 extended sequencing option is controlled by the R&S®Pulse Sequencer software and its options R&S®SMW-K300 and R&S®SMW-K301. In both cases, memory requirements are reduced to a minimum and playtime is increased enormously.

The extended sequencing option is mainly intended for use with pulsed signals. It is based on a sequencing file that defines the relative start time of each pulse and additionally specifies parameters such as amplitude, offset frequency and phase. Pulses with rectangular envelope and common MOP types can be entirely generated in real time and do not require a waveform segment at all.

Parameter type		
Data format		
Sequencing file		mandatory, memory shared with I/Q data and segment addresses
I/Q data file		optional
Segment addresses		optional
Memory requirements		
Sequencing file	minimum	14 byte/pulse
	maximum	32 byte/pulse
Segment addresses		16 byte/waveform segment
I/Q data file		4 byte/I/Q sample
File size		
Sequencing file	rectangular pulses, unmodulated, variable amplitude, 5 ms PRI	187 kbyte/min
	rectangular pulse, linear FM, variable FM, variable amplitude, phase and frequency, 5 ms PRI	305 kbyte/min
Setting granularity		
Time	with R&S®SMW-B9 option	417 ps
Amplitude		16 bit (voltage-based)
Phase		< 0.01°
Frequency	with R&S®SMW-B9 option	0.58 Hz
I/Q segments		
Maximum individual segments		16 777 216
Length granularity	with R&S®SMW-B9 option	32 samples
Timing		
Maximum play time	with R&S®SMW-B9 option	2 h
Minimum pulse width	with R&S®SMW-B9 option, real time	3.3 ns
	with R&S®SMW-B9 option, I/Q segment	417 ps
Minimum PRI/frequency switching	with R&S®SMW-B9 option, real time	0.3 µs
	with R&S®SMW-B9 option, I/Q segment	1 µs
Limitations		
Settings disabling extended sequencing data generation		non-0/100 timing, no blank signal between pulses, short PRI
Settings permitting real time pulse generation		rectangular pulse envelope, unmodulated or real time MOP
Real time MOP types		
Unmod		rectangular pulse
Linear FM		up, down, triangular
Phase		Barker
Marker signals		
Number of marker signals		3
Marker types	default M1, M2, M3	active during pulse
	sequence start signal enabled	M1 active at sequence start

Pulse-on-pulse simulation

R&S®SMW-K315

This option can be used for two different applications:

- Radar signal generation using PDW streaming with R&S®SMW-K503/-K504. Please refer to the R&S®SMW200A data sheet (PD 3606.8037.22)
- Radar signal generation with R&S®Pulse Sequencer software, which is described here

The option allows to generate up to six permanent (simultaneous) baseband signals in a single instrument. It allows the generation of time overlapping pulse-on-pulse signals. Thus up to six emitters can be generated simultaneously on one R&S®SMW200A. If the option R&S®SMW-K306 is installed, each extended sequencer can also be used to generate a group of interleaved emitters. In case of interleaving emitters, drop-out rates can be reduced by distributing emitters onto more hardware resources.

The K315 option in combination with R&S®Pulse Sequencer software is only available as add-on to the combination of the following minimum instrument configuration: 2 × R&S®SMW-B9 + 2 × K300, 2 × K301, 2 × K502 and 2 × R&S®SMW-B15 options. This particular configuration allows four extended sequencers for processing signals or emitters. The number of R&S®SMW-B15 boards can be increased to four in order to enable six pulse-on-pulse emitters. The complexity of a data repository has to be set to advanced K300/K301 or to K308 mode.

Dynamic frequency selection (DFS)

For R&S®SMW-K350, R&S®SMBV-K350, R&S®SMBVB-K350, R&S®SMU-K350, R&S®SMJ-K350, R&S®SGT-K350

The R&S®Pulse Sequencer (DFS) software is limited to the features required for DFS signal generation. The software comes with preconfigured projects for the standards listed below. All test signals are generated as ARB waveforms and automatically uploaded to the vector signal generator. In addition an excel spread sheet is generated that contains all signal parameters that were used during waveform generation.

National standards

Standard	Last modification
USA	
FCC 0696	14.09.2016
FCC 1322	14.09.2016
FCC KDB 905462 D02	14.07.2017
Europe	
ETSI EN 302502 V2.0.8	06.06.2017
ETSI EN 301893 V1.8.5	06.06.2017
ETSI EN 301893 V1.8.1	13.09.2016
ETSI EN 301893 V2.1.1	05.12.2018
ETSI EN 301893 V1.7.2	25.07.2016
ETSI EN 302502 V1.2.1	06.06.2017
ETSI EN 303258 V1.0.0	25.07.2016
Japan	
MIC-W53/-W56	02.05.2016
MIC-W53/-W56 07_2019 update	02.10.2019
Korea	
Korea	22.06.2016
China	
YD/T 2950-2015	15.11.2017

USA

FCC 0696	
Signal types	1, 2, 3, 4, 5, 6 band limited hopping
Marker 1	end of burst
Marker 2	every pulse
Reporting	template or excel spread sheets
Trials per signal	30, automatically generated
FCC 1322	
Signal types	0, 1, 2, 3, 4
Marker 1	end of burst
Marker 2	every pulse
Reporting	template or excel spread sheets
Trials per signal	30, automatically generated
FCC KDB 905462 D02 New Rules v02	
Signal types	0, 1, 2, 3, 4, 5, 6 band limited hopping
Marker 1	end of burst
Marker 2	every pulse
Reporting	template or excel spread sheets
Trials per signal	30, automatically

Europe

ETSI EN 302502 V2.0.8		
Signal types		1, 2, 3, 4, 5, 6, D3.2-S1, D3.2-S2
Marker 1		end of pulse
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		30, automatically generated
ETSI EN 301893 V2.1.1		
Signal types		reference, 1, 2, 3, 4, 5, 6, OFDM, LTE
Marker 1		end pf pulse
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		20, automatically generated
ETSI EN 301893 V1.8.5		
Signal types		reference, 1, 2, 3, 4, 5, 6
Marker 1		end of pulse
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		20, automatically generated
ETSI EN 301893 V1.8.1		
Signal types		reference, 1, 2, 3, 4, 5, 6
Marker 1		end of pulse
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		20, automatically generated
ETSI EN 301893 V1.7.2		
Signal types		reference, 1, 2, 3, 4, 5, 6
Marker 1		end of pulse
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		20, automatically generated
ETSI EN 302502 V1.2.1		
Signal types		1, 2, 3, 4, 5, 6, D3.2-S1, D3.2-S2
Marker 1		end of pulse
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		30, automatically generated
ETSI EN 303258 V1.0.0		
Signal types		reference, 1, 2, 3, 4
Marker 1		end of burst
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		20, automatically generated

Japan

MIC-W53/-W56		
Signal types		W53 1, 2; W56 1, 2, 3, 4, 5, 6; W56 band limited hopping
Marker 1		end of burst
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		30, automatically generated
MIC-W53/-W56 07_2019 update		
Signal types		W53 1, 2, 3, 4, 5, 6, 7, 8; W56 1, 2, 3, 4, 5, 6; W56 band limited hopping
Marker 1		end of burst
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		30, automatically generated

Korea

Korea		
Signal types		1, 2, 3
Marker 1		end of burst
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		1, automatically generated

China

YD/T 2950-2015		
Signal types		reference, 1, 2, 3, 4, 5, 6
Marker 1		end of burst
Marker 2		every pulse
Reporting		template or excel spread sheets
Trials per signal		20, automatically generated

PDW report generation

Pulse description words (PDW) describe the main properties of a single pulse. The R&S®Pulse Sequencer software can generate PDW reports during a waveform build process.

Report types		
Default		
Format		text (table), format can be customized
Parameters		TOA, RF center frequency, pulse width, power level, MOP type, bandwidth
Template		
Format		text (table)
Parameters		TOA, RF frequency, power level, MOP type, bandwidth, PRI, PRF, pulse width, rise time, fall time, phase, AOA (emit azi, emit ele), rx scan azi, rx scan ele, sequencing parameters, custom variables
Plugin		
Format		64 bit Windows .dll, API specified in user manual

Path loss compensation

The R&S®Pulse Sequencer software provides built-in routines for path loss compensation.

Alignment database location		home path, network drive, mass storage on signal generator
Compensation method		scalar level offset versus frequency
Supported power sensors		
R&S®NRPxxSN, R&S®NRPxxTN, R&S®NRPxxAN		directly via LAN, connected to signal generator (legacy mode)
R&S®NRPxxS, R&S®NRPxxT, R&S®NRPxxA		directly via USB, connected to signal generator (legacy mode)
R&S®NRP-Zxx		connected to signal generator

Supported generators

The R&S®Pulse Sequencer software uses generator profiles to describe minimum requirements that must be met for signal generation. For the generation of a real signal these generator profiles must be linked to physical instruments. The following signal generators are supported.

Signal generator		
R&S®SMW200A		
Options		R&S®SMW-K300, R&S®SMW-K301, R&S®SMW-K302, R&S®SMW-K304, R&S®SMW-K306, R&S®SMW-K308, R&S®SMW-K309, R&S®SMW-K350
R&S®SMBV100A		
Options		R&S®SMBV-K300, R&S®SMBV-K301, R&S®SMBV-K308, R&S®SMBV-K350
R&S®SMBV100B		
Options		R&S®SMBVB-K300, R&S®SMBVB-K301, R&S®SMBVB-K308, R&S®SMBVB-K350
R&S®SMU200A		
Options		R&S®SMU-K350
R&S®SMJ100A		
Options		R&S®SMJ-K350
R&S®SGT100A		
Options		R&S®SGT-K300, R&S®SGT-K301, R&S®SGT-K308, R&S®SGT-K350

Remote control

Interfaces		raw socket connection
Command set		SCPI 1999.5 or compatible command sets
Parameters		
Host		IPv4 address and port number
Access control		allow and deny list

PC hardware requirements

Minimum hardware configuration		
Operating system		Windows 10, 64 bit
CPU		dual-core, 3 GHz
RAM		8 Gbyte
Video		NVIDIA Quadro 128 Mbyte or ATI Radeon
Video resolution		1280 × 1024 pixel
Rendering		OpenGL, shader model 3
Network		LAN, 1 Gbyte/s
Recommended hardware configuration		
CPU		Intel i7 hexa-core, Intel Xeon hexa-core, AMD FX series
RAM		32 Gbyte
Video resolution		1920 × 1200 pixel

Ordering information

Designation	Type	Order No.
Pulse sequencer options for R&S®SMW200A		
Options with external R&S®Pulse Sequencer software or R&S®Pulse Sequencer (DFS) software		
Pulse sequencing	R&S®SMW-K300	1413.8805.02
Enhanced pulse sequencing	R&S®SMW-K301	1413.9776.02
Radar platforms	R&S®SMW-K302	1413.8857.02
Moving emitters	R&S®SMW-K304	1413.8957.02
Multiple emitters	R&S®SMW-K306	1413.9053.02
Direction finding	R&S®SMW-K308	1414.1433.02
2D map import	R&S®SMW-K309	1414.6706.02
Pulse-on-pulse simulation	R&S®SMW-K315	1414.6529.02
DFS signal generation	R&S®SMW-K350	1413.9160.02
Extended sequencing	R&S®SMW-K501	1413.9218.02
Wideband extended sequencing	R&S®SMW-K502	1413.9260.02
Pulse sequencer options for R&S®SMBV100A		
Options with external R&S®Pulse Sequencer software or R&S®Pulse Sequencer (DFS) software		
Pulse sequencing	R&S®SMBV-K300	1419.2744.02
Enhanced pulse sequencing	R&S®SMBV-K301	1419.2780.02
Direction finding	R&S®SMBV-K308	1419.2973.02
DFS signal generation	R&S®SMBV-K350	1419.2767.02
Pulse sequencer options for R&S®SMBV100B		
Options with external R&S®Pulse Sequencer software or R&S®Pulse Sequencer (DFS) software		
Pulse sequencing	R&S®SMBVB-K300	1423.8414.02
Enhanced pulse sequencing	R&S®SMBVB-K301	1423.8420.02
Direction finding	R&S®SMBVB-K308	1423.8437.02
DFS signal generation	R&S®SMBVB-K350	1423.8443.02
Pulse sequencer options for R&S®SGT100A		
Options with external R&S®Pulse Sequencer software		
Pulse sequencing	R&S®SGT-K300	1419.7652.02
Enhanced pulse sequencing	R&S®SGT-K301	1419.7700.02
Direction finding	R&S®SGT-K308	1419.7730.02
DFS signal generation	R&S®SGT-K350	1419.8107.02
Pulse sequencer options for R&S®SMU200A		
Option with external R&S®Pulse Sequencer (DFS) software		
DFS signal generation	R&S®SMU-K350	1408.8830.02
Pulse sequencer options for R&S®SMJ100A		
Option with external R&S®Pulse Sequencer (DFS) software		
DFS signal generation	R&S®SMJ-K350	1409.3702.02

Service that adds value

- ▶ Worldwide
- ▶ Local and personalized
- ▶ Customized and flexible
- ▶ Uncompromising quality
- ▶ Long-term dependability

Rohde & Schwarz

The Rohde & Schwarz electronics group offers innovative solutions in the following business fields: test and measurement, broadcast and media, secure communications, cybersecurity, monitoring and network testing. Founded more than 80 years ago, the independent company which is headquartered in Munich, Germany, has an extensive sales and service network with locations in more than 70 countries.

www.rohde-schwarz.com

Sustainable product design

- ▶ Environmental compatibility and eco-footprint
- ▶ Energy efficiency and low emissions
- ▶ Longevity and optimized total cost of ownership

Certified Quality Management
ISO 9001

Certified Environmental Management
ISO 14001

Rohde & Schwarz training

www.training.rohde-schwarz.com

Rohde & Schwarz customer support

www.rohde-schwarz.com/support

